
















Hot Key functions

Icon	Windows	Android	IOS
Fn + 	New web window	Home screen	Home screen
 1	Bluetooth channel 1	Bluetooth channel 1	Bluetooth channel 1
 2	Bluetooth channel 2	Bluetooth channel 2	Bluetooth channel 2
 3	Bluetooth channel 3	Bluetooth channel 3	Bluetooth channel 3
	Previous track	Previous track	Previous track
	Play/Pause	Play/Pause	Play/Pause
	Next track	Next track	Next track
	Mute	Mute	Mute
	Volume -	Volume -	Volume -
	Volume +	Volume +	Volume +
	Brightness -	Brightness -	Brightness -
	Brightness +	Brightness +	Brightness +
	Battery charge level	Battery charge level	Battery charge level
Fn + 	Screen lock/unlock	Screen lock/unlock	Screen lock/unlock
Fn + 	Back	Back	Back

ERGOAPT

Groove Keyboard

OPC11BG

User Manual



Contents

- 1 x Ergoapt Groove Bluetooth keyboard
- 1 x Charging cable
- 1 x User manual

Keyboard specifications

Compatible systems:	Windows, Android, IOS
Sleep time:	Idle for 30 minutes
Charging time:	2 - 4 hours
Operating distance:	Up to 10m

The Ergoapt Groove can be paired to up to 3 Bluetooth devices. Once the devices are paired to the keyboard, press the channel keys to switch between devices.

Channel keys



Indicator lights

 **Bluetooth indicator:** Flashes blue when in pairing mode.

 **Caps Lock indicator:** Blue light appears when Caps Lock is on.

Power/Charging/Battery:

Power: When the keyboard is turned on, the blue light will appear for 3 seconds.

Charging: When the keyboard is charging the light will be red. When the keyboard is fully charged, the light will turn off.

Battery: Flashes 4 times = 76% - 100% charge

Flashes 3 times = 51% - 75% charge

Flashes 2 times = 26% - 50% charge

Flashes 1 times = 1% - 25% charge

How to charge

Use the included USB cable to charge the keyboard.

While charging the power indicator will turn red.

It will take approximately 2 - 4 hours for a full charge.

Energy saving mode

The keyboard will enter sleep mode after being idle for 30 minutes.

To wake the keyboard press any key. The keyboard will wake after 4 seconds.

When not in use for a prolonged period of time, it is recommended that the keyboard be switched off to conserve the battery life.

Pairing steps

1. Switch on the keyboard, the Power light will appear for 3 seconds.
2. Place the keyboard into pairing mode by holding down a channel key for 5 seconds:



3. When the pairing light starts blinking slowly, the keyboard is in pairing mode.
4. Open up Bluetooth Settings on the device, select **Ergoapt Groove** from the list.
5. When the light stops blinking, the device is paired to the selected channel key.
6. Repeat the above steps to pair devices to the other channels keys.

Once the devices are paired to the keyboard, press the channel keys to switch between devices.

Troubleshooting

If you are unable to connect the keyboard to a device, follow the below steps:

1. Ensure that the keyboard and device have full battery charge so that the connection is not interrupted by a loss of power.
2. Confirm that the device's Bluetooth is turned on and searching for connections.
3. Ensure that the keyboard is in pairing mode.
4. Place the keyboard and device within 10m of each other.