

ADJUSTMENT OF SEAT TILT / BACK TILT CLUTCH ON 3-LEVER MECHANISM INSTRUCTIONS

If a client experiences the Seat Tilt or Back Tilt not holding position on their chair, a minor clutch adjustment of the 3-lever mechanism is required. The manufacturers do not classify this as a warranty issue, but general maintenance on the mechanism.

This adjustment will tighten the clutch and allow the mechanism to hold position again.

To make the adjustment, you will require an adjustable spanner and possibly a flat head screwdriver, to remove the plastic nut cover.

ADJUSTMENT INSTRUCTIONS

- 1 Locate the lever that operates the “Seat Tilt or Back Tilt” 1



REQUIRED
ADJUSTABLE SPANNER
OPTIONAL
FLATHEAD SCREWDRIVER



- 2 Follow the lever to the opposite side of the mechanism to locate the “Bolt Nut” plastic cover cap 2 and remove cap.



- 3 Using an adjustable spanner, turn the nut ¼ of a turn clockwise. 3 Check the seat tilt no longer slips. If it still doesn't hold position, repeat the above step another quarter of a turn, until the clutch holds.

