



6.



Once the drawer is inserted, lock it into place using the provided locking mechanism.

Test the drawer by opening and closing it a few times to ensure that it moves smoothly and remains secure when closed.

7.




The AG unit can support a maximum weight of 12 kilograms on the lower shelf, while the Drawer Insert (B) has a weight limit of 3 kilograms.

Before using the unit, double-check that all attachments are securely in place and that the AG is stable on the desk.





This guide ensures a secure and efficient assembly process. If any part feels loose or unstable, recheck the fastenings before placing items on the AG unit.

Anti-Gravity Assembly Instructions




Parts List - Elevar Anti-Gravity

Please ensure all parts are present before assembly


a		AG	1x	e		Anti Slip Mat	1x
b		Drawer	1x	f		Felt Drawer Insert	1x
c		Bag Hook	1x	g		Allen Key	1x
d		Leg Lock	1x	h		Cable Clips	3x

Assembly - Elevar Anti-Gravity




Begin by placing the AG unit on the desk, ensuring that the top surface is parallel to the desk's edge.

Carefully align the AG in the correct position, making sure that the mounting area is stable and secure before proceeding to the next step.



Use the Allen Key (G) to tighten the mounting screws located on the underside of the AG unit. Secure the knob (D) by turning it clockwise to fasten the unit properly to the desk.


Before continuing, check that the AG is firmly attached and does not shift when pressure is applied.



Locate the designated mounting area for the Bag Hook (C) on the side of the AG.


Insert the bag hook into place and ensure that it is securely fastened.

Once attached, verify that it is stable and capable of supporting the weight of a bag.



Place the Anti-Slip Mat (E) on the top surface of the AG unit, ensuring that it lies flat and covers the designated area.

Insert the Felt Insert Mat (F) inside the lower compartment, making sure it fits snugly.



Take the Drawer Insert (B) and align it with the guide rails inside the AG unit.

Carefully slide the drawer into place, ensuring that it moves smoothly along the rails.

Push the drawer fully inside to check that it is properly fitted and functional.